


Green Thumb Planter


EC-022
Installation Instructions



| DET. | QTY. | PART# | DESCRIPTION | ICON (NOT TO SCALE) |
|------|------|--------|---|---------------------|
| A | 1 | L762_ | Green Thumb Enclosure | |
| B | 1 | 9858 | Cornice 40-9/16", Green Thumb | |
| C | 2 | L551 | Green Thumb Enclosure Panel | |
| D | 1 | 3107 | Green Thumb Enclosure Panel Support Board | |
| E | 2 | Z004 | Column 4'-0" | |
| F | 4 | G000 | Eagle Fastener | |
| G | 20 | 401232 | Hole Plug Grey Eagle | |
| | 1 | D107_ | Connector, Green Thumb Enclosure | |
| H | 4 | 817412 | Washer 1/2" SAE Pltd | |
| I | 4 | 817201 | Lock Washer, 1/2" Int Tooth Type A PLTD | |
| J | 4 | 801221 | Bolt Tap 1/2-13 x 5-1/2" NC Pltd | |
| K | 2 | 800807 | Bolt Tap 1/2-13 x 5" NC Pltd | |
| L | 2 | 804355 | Nut Hex 1/2-13 2-Way Locknut Nc Pltd | |
| M | 4 | G034_ | Do-Nut Base (No Boss) 12mm | |
| N | 4 | G036_ | Do-Nut Cap 12mm | |
| O | 4 | 815511 | Wood Screw #10 x 3" Bugle Hd Sq Dr SS | |


Continued

| | | | |
|---|-------|-------------------|---------------------------------------|
| 2 | D010_ | Connector, Column | |
| P | 2 | 401233 | End Cap |
| Q | 2 | 401231 | Column End Fitting - Wood |
| R | 6 | 810060 | Screw, Sht Metal FH SQ DR #10 x 2" SS |
| S | 2 | 401991 | Column Footing Pipe 10" |



1. Refer to your Structure Design for location and orientation of **Green Thumb Planter**.


If your **Green Thumb Planter** is not attached to a structure, **lay out and dig footing holes** as shown. (See "Ground Level Activity Footing" in "Typical Concrete Footings.")



2. **Install Eagle Inserts (F) in Columns (E).** (See "Typical Eagle Fastener Installation).")



Refer to "Typical Eagle Fastener Installation" in the supplemental prolog (iZ1000) for installation procedures.




Standard Footing


(1.2 to 1.9 cubic feet of concrete)**

**Depth of Resilient Surface will vary depending on the type of Surfacing used. (See enclosed USCPSC Report.)*


*** The concrete volumes listed are approximations based on the maximum and minimum resilient surface thickness' available. Varying soil conditions may also affect volumes.*




3. Slide **Enclosure Panel (C)** in before attaching to columns.




5. Insert hardware (N)(L)(M)(K) through panels (C) to support **Enclosure Support Board (D)**.



4. Attach **Enclosure** to columns with hardware (H)(I)(J). Place **Enclosure Support Board (D)** in the center and line up holes in **Panel (C)**.




6. Attach Top **Cornice (B)** with **Wood Screws (O)**.



7. Attach **Column End Fitting (Q)** and **End Cap (P)** to the top of columns using **Screws (R)**.

8. Install **Hole Plugs (G)** in all open holes.



9. Insert **Footing Pipe (S)** into hole at the base of the column.