



# PLAN



# ELEVATION



## Large Stepping Stones UP501



**NatureROCKS™**  
A boulder way to play!™

**ultraPLAY®**

A PLAYCORE Company

# INSTALLATION INSTRUCTIONS

## Tools Required:

- Skidster or Fork Lift Truck
- Shovel /Auger
- Nylon lifting strap, minimum 8' length  
Note: Rated for 1,000 lbs. minimum
- Concrete  
Note: Rated for 2,500 psi minimum

**Weight:** 500 lbs. per Large Stepping Stone

**Step 1:** Thoroughly inspect all pieces before unloading for damages incurred during shipping.

**Step 2:** Establish layout of Large Stepping Stone and dig footing holes.

**Note:** Actual dimensions of products may vary slightly from drawing. Confirm actual tab and hole locations.

**Step 3:** Carefully place Large Stepping Stone so that steel tabs align with footing holes.

**Step 4:** Attach J-bolts (Qty = 3) to steel tabs at the base of the Large Stepping Stone. Make sure J-bolts are centered in footing holes. Fill footing holes with concrete.

**Step 5:** Once concrete has hardened, remove all remaining packaging materials and inspect piece for blemishes. Use included touch-up kit as needed.

# GENERAL NOTES

- Due to variables in local soil conditions, footing sizes may vary to meet local codes.
- Actual on-site conditions may vary and may require modifications to installation method.
- Use care and caution while handling play pieces. Make sure all points of contact are protected from lifting straps or other machinery that may damage the piece.
- Bracing materials may be required during installation.
- Recommended spacing is no greater than 12" to 18" apart for stepping stones. Consult your playground safety guide for your application.

**NatureROCKS™**  
*A boulder way to play!™*

**ultraPLAY®**

A PLAYCORE Company